

How To Fit 'Submarine' Lighting To The Fiesta ST


1. Using a wide flat headed screw driver or knife, carefully prise the old interior light from its housing.



2. Pass the red wire (plain end) under the headlining and out from the top of the windscreen.



3. Carefully push the wire under the edge of the headlining, under the door weather seal/ windscreen pillar trim. Push the wire behind the dash.









4. Using a wide flat headed screw driver or knife, carefully prise the exterior light switch out from its housing.







5. Remove the multi plug from the back of the light switch and pull the red wire out from behind the dash.



6. Using the supplied lock connector, connect the red wire to the Orange/Blue Stripe wire. This will switch the 'submarine' lights on when the side/headlights are switched on.



7. Reconnect the light multi plug and push the light switch back into its housing.
8. Push the other spade connected end of the red wire onto the connector on the underside of the new interior light unit.



9. Push the new interior light unit back into its housing.



10. Switch on your side/headlights and the red submarine lights should illuminate.



* To add to the red submarine lighting, you can also replace the clear 'interior' light bulb for a red LED version (Available separately)

