



## Service Schedule

<b>Model</b>	Focus 2008	<b>Repair/Order No</b>	
<b>Variant</b>	DURATEC 16V/MANUAL (12/2007 - 07/2011)	<b>Reg. No.</b>	
<b>Interval</b>	7 Years (105000 km)	<b>Reg. Date</b>	
		<b>Radio Code</b>	
		<b>Mileage</b>	km

### Outstanding Field Service Actions. Please ensure they are completed.

No Campaign Message(s) found

### Driving Vehicle into Workshop

Instrument gauges, warning/control lights and horn	Check operation
Clutch	Check operation/adjust, if necessary
Washers, wipers	Check operation/adjust, if necessary

### Inside Vehicle

Exterior and respective control lights; instrument cluster illumination	Check operation/condition
Handbrake	Check operation/adjust, if necessary
Seat belts, buckles and stalks	Check operation/condition
Odour filter	Renew
Warning vest	Check availability - if applicable
First aid kit	Check availability and expiry date - if applicable
Warning triangle	Check availability - if applicable

### Outside Vehicle

Road (MOT) test	Check regarding next road (MOT) test due date - if applicable
Emission test	Check regarding next emission test due - if applicable

### Under Hood

Wiring, pipes, hoses, oil and fuel feed lines	Check for routing, damage, chafing and leaks
Engine, vacuum pump, heater and radiator	Check for damage and leaks
Coolant	Check anti-freeze concentration: ____ °C
Coolant expansion tank, washer reservoirs and battery	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify
Power steering fluid	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify
Battery	Visual check for leaks - in case of abnormal fluid loss, a separate order is required to investigate and rectify (LTS 31 214 4)
Headlamp alignment	Check - adjust alignment, if necessary
Brake fluid	Check/top up fluid levels as necessary - in case of abnormal fluid loss, a separate order is required to investigate and rectify

### Under Vehicle

Engine undershield	Remove/install engine undershield, if fitted (LTS 21 130 4)
Engine	Drain oil and renew oil filter
Steering, suspension linkages, ball joints, driveshaft joints, gaiters	Check for damage, wear, security and rubber deterioration
Engine, transmission	Check for damage and leaks
Pipes, hoses, wiring, oil and fuel feed lines, exhaust	Check for routing, damage, chafing and leaks
Underbody +	Check condition of PVC coating
Tyres	Check wear and condition, especially at tyre wall, note tread depth RF ____mm, LF ____mm, LR ____mm, RR ____mm
Brake system	With wheels on, check brake pads and discs for wear. Check rear brake drums - in case of abnormal fluid loss, a separate order is required to investigate and rectify. (More often under severe duty conditions).

### Outside Vehicle

Engine	Refill engine oil. Reset the oil change indicator, if fitted.
Tyres	Adjust pressure
Instant mobility system	Check best before date on tyre sealant - if applicable

<b>Outside Vehicle</b>	
<b>Spare wheel</b>	Adjust pressure, check wear - condition (note tread depth) _____mm
<b>Luggage compartment lamp +</b>	Check operation - if applicable
<b>Service reminder sticker</b>	Affix to driver side B pillar
<b>Extended Period Maintenance</b>	
<b>Brake system</b>	Every 2 years - Renew - brake fluid (LTS 12 154 4)
<b>Air conditioning</b>	Every 3 years - Check temperature at the evaporator outlet tube. Check air conditioning lines for damage and leaks (LTS 34 619 1) (TSB 67/2002)
<b>Cooling system</b>	Every 10 years - Drain, flush and refill with Super Plus (LTS 24 122 4)
<b>Camshaft drive belt</b>	Every 120 000 km/8 years - Renew (LTS 21 304 9)
<b>Auxiliary drive belts</b>	Every 120 000 km/8 years - Renew (LTS 21 567 5)
<b>Visual body &amp; paint check</b>	Every 12 or 24 months depending on vehicle type and build year/registration date. Carry out during operations marked (+) above - see detailed Check Sheet - if applicable (LTS 54 555 1 +)
<b>Extra Services and Additional Offers * (optional - upon customer request / charged seperately)</b>	
<b>AC maintenance package</b>	Air Conditioning (A.C.) system check. Apply A.C. cleaner to air distribution system. (LTS 54 552 4)
<b>Odour filter plus</b>	Upgrade odour filter to odour filter plus
<b>Test Drive</b>	
<b>Test drive</b>	Perform test drive after routine service

+ Visual body and paint check should be carried out during these operations on vehicles built from 03/2002 onwards - see detailed Check Sheet if applicable.

Separate labour charge dependant on market regulations.